


For use with these part numbers:


383283	383492
383316	383558

Inventory

2' (61cm)	0
3' (91cm)	0
3½' (107cm)	2
4' (122cm)	0
5' (162cm)	2
6' (183cm)	14
Stiffener	22
	4



Beware of Pinch Points



Before assembling StageScreen:

- Spread the tarp (included)
- Lay the viewing surface facedown on the tarp
- Assemble the frame on top of the screen surface
- Frame sections should be arranged so that:
 - A. Viewing surface attachment posts are on the outside of the frame
 - B. Guide pins should go **CLOCKWISE**
 - C. Rivets should face **UPWARD**
- Red dots above indicate recommended attachment points for flying or wall bracket.