


For use with these part numbers:


383276	383485
383309	383551

Inventory

2' (61cm)	0
3' (91cm)	4
3½' (107cm)	2
4' (122cm)	0
5' (162cm)	0
6' (183cm)	2
Stiffener	6
	4



Beware of Pinch Points



Before assembling StageScreen:

- Spread the tarp (included)
- Lay the viewing surface facedown on the tarp
- Assemble the frame on top of the screen surface
- Frame sections should be arranged so that:
 - A. Viewing surface attachment posts are on the outside of the frame
 - B. Guide pins should point CLOCKWISE
 - C. Rivcups should face UPWARD
- Red dots above indicate recommended attachment points for flying or wall bracket.

