

Overview

The IntelliFlex I/O Sensor / Scheduler Interface allows up to 4 sensors to be added to an IntelliFlex I/O network. Includes built-in support for brightness, wind and precipitation sensors as well as pyranometers. Also provided support for up to 8 scheduled override events. Configuration is done using on-board buttons and LCD display.

Features


- Supports 0-10V, 4-20mA, photodiode and pulse sensors
- Simple configuration using built-in buttons and LCD display
- Scheduled events can be configured to run on any combination of days of the week
- External power input for sensors provides support for any sensor power requirements



Technical Specifications - Sensor/Scheduler Interface

Material:	ABS plastic	
Operating Temp:	Ambient	
Dimensions:	4 7/8" x 3" x 1"	124 x 76 x 25mm
Mounting:	Mounting Hardware Provided	
Shipping Weight:	1 lb.	0.45 kg
	Indoor Use Only	
	NDC Required (included)	
	Optional Power Supply: (C103.154)	

IntelliFlex I/O the complete control solution for Motorized FlexShades®



IntelliFlex I/O Compatible Components	Part Number
Single Zone Wired Wall Switch (S1)	C112.161
Dual Zone Wired Wall Switch (S2)	C112.162
Handheld RF Remote (RFR)	C156.270
IR Transmitter and Receiver (IRT/R)	121227
IR Transmitter (IRT)	121228
Network Device Connector (NDC)	C156.267
Wireless Network Gateway (WNG)	C156.268
AV Gateway (AVG)	C156.269
Sensor/Scheduler Interface (SSI)	C156.272
SSI w/ Automated glare control (SSI+)	C156.304
Contact Closure Interface (CCI)	C156.273
Central Network Controller (CNC)	C156.271
IP Gateway (IPG)	C156.305
3-Port Network Device Connector (NDC3)	C156.311
1 Motor Controller w/enclosure (1MC)	C156.285SA
1 Motor Controller (1MC)	C156.285
4 Motor Controller w/enclosure (4MC)	C156.286SA
Motor Limit Tool (MLT)	C202.047
IntelliFlex I/O Installation Kit (IO-Kit)	C504.206SA

For info on other I/O compatible products, visit draperinc.com.

For low voltage wiring requirements, Draper recommends consulting with a professional low voltage electrical contractor. **All low voltage wiring must be run separately from line voltage wiring.**